Forklift Pre Start Checklist ☐ Pre start checklist is to be completed every day prior to using the equipment. Operator is to initial when inspected, Supervisor is to review the checklist and sign off at the end of each week. ☐ Seat Belts to be worn where fitted. Forklift Type...... Forklift Number....... Date (Week Commencing Mon)..... W М S S Initials of person doing inspection Tick if item is acceptable, cross if it is not TYRES – check they are in good condition, intact with rim. Look for visual wear or damage. Check tyre pressure FLUIDS - check oil, hydraulics, battery, fuel and coolant for leaks including hoses under fork lift STRUCTURE – check for cracks, bends, dents, distortion or broken parts. Check apron & overhead guards are intact & secure TINES/FORKS - check they are evenly spread with locking pins in place. Check there is no sharp edges or distortion MAST - check chains are level with no obstructions, rams not pitted or leaking. Check for any wear to lift chains and guides, inspect hydraulic cylinders, look for any leaks BATTERY - check it is operational and for any damage BATTERY CHARGE - discharge meter in full green or 75% after raising forks (where applicable) GAS OPERATED FORKS - check gas levels are ok and gas cylinder is not damaged damage. Check gas cylinder is secure ENGINE BAY - check it is generally clean? Hydraulic oil-brake pads and brake fluid (cb machines only). CONTROLS (pre start) - check seat condition. Check controls are clearly marked, seat & steering wheel are secure & properly adjusted. Seat belt (where fitted) works as intended. CONTROLS (post start) - check controls and pedals are working. No unusual noises. CAPACITY/LOAD PLATE - check load-capacity plate if fitted, legible and correct. What is your safe working load (inc when travelling, tilted & lifting)? REVERSE BUZZER & HORN - check working LIGHTS & BEACON - check working STEERING - check smooth from lock to lock, no binding BRAKES - check both brake & park brake for proper operation SAFTEY PEDAL - check the motor cuts out POWER DISCONNECT - check all electric power cuts out HYDRAULICS - Operate lift, tilt & reach to full extent of travel GUARDS - check overhead, load backrest ATTACHMENTS – check they function correctly, no unusual noises If any items above are not working, the forklift is to be tagged out and reported to the supervisor for repair. Description of Issue.....

Weekly Supervisor sign off.....